



Laundry Box





MOUNTING AND MAINTENANCE GUIDE













ReCollector




ReCollector




- F1 x8 (6405830)
- F2 x8 (3012760)
- F3 x6 (3012159 ø3,5x16)
- F4 x4 (3012161)
- F5 x2 (3012602)
- F6 x8 (3012681)
- F7 (3012160)
- F8 x2 (3012157 ø3x16)
- F9 (3012162)
- F10 x2 (3012148 ø3x20)
- F11 x8 (6500425 ø4,5x25)
- F12 (3012160)
- F13 x2 (3012423)
- F14 x8 (6202316)
- F15 x4 (6201070)
- F16 x2 (6500570)




1




2




3




4




5




6





7





8




9



10



11



12

